




**ALARM CLOCK RADIO  
MODEL: DLCR606**


**INSTRUCTION MANUAL**

 <p>This lightning flash and arrowhead within the triangle is a warning sign alerting you of "dangerous voltage" inside the product.</p>	<p><b>CAUTION</b> <b>RISK OF ELECTRIC SHOCK</b> <b>DO NOT OPEN</b></p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (ON BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>	 <p>The exclamation point within the triangle is a warning sign alerting you of important instructions.</p>
--	---	---

**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,  
DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE.**

Please read this before operating your unit.

1. To Turn the radio ON/OFF Button
2. Radio Frequency/Band or Volume Selection Button
3. Time Set / Station Preset Button
4. + Set Button
5. Sleep Timer Button
6. AL1 Button (Alarm 1 On/Off)
7. AL2 Button (Alarm 2 On/Off)
8. – Set Button
9. Snooze Button
10. PM indicator
11. Wake to Buzzer Indicator (Alarm 1)
12. Wake to Radio Indicator (Alarm 1)
13. FM Indicator
14. Wake to Buzzer Indicator (Alarm 2)
15. Wake to Radio Indicator (Alarm 2)



### **CONNECTING POWER**

1. Plug the unit to the AC 120V 60Hz socket outlet.
2. Insert 2 pieces of AAA 1.5V battery (not included) into the battery compartment.

### **SETTING THE CLOCK**

#### **TO SET THE CLOCK FOR THE FIRST TIME**

1. Plug the unit to the socket outlet and the clock display will flash with the hour digits.
2. Press the + or – Button to adjust the hour. The PM Indicator will light up when you set the hour to PM time.
3. Press the TIME Button to confirm the hour. The minute digits will be flashing.
4. Press the + or – Button to adjust the minute.
5. Press the TIME Button to confirm the minute.

Note: in future you can also adjust the time by pressing and holding the 'TIME' Button for 2 seconds in clock mode (radio off). The hour digits will start to flash. Then you can follow the step 2 to step 5 to adjust the time.

### **USING THE ALARM**

#### **TO SET THE ALARM**

You can set two alarms (ALARM 1 & 2) with the following steps:

1. Turn the unit to Clock mode (radio off).
2. Press and hold the AL1 Button for 2 seconds. The hour digits will start to flash.
3. Press the + or – Button to adjust the hour.
4. Press the AL1 Button for confirmation. The minute digits will start to flash.

5. Press the + or – Button to adjust the minute.
6. Press the AL1 Button for confirmation.
7. Press the AL1 Button for selection of how you want to be awakened.
  - A red LED lights up at Bell symbol means a buzzer sounds when the alarm time is reached.
  - A red LED lights up at Music Note symbol means the radio will be switched on at the last set station when the alarm time is reached.
8. You can turn off the alarm by pressing the AL1 Button repeatedly until no LED lights up at the symbols.

Note: you can set the ALARM 2 by repeating the above steps with the AL2 Button.

### **TO REVIEW THE ALARM**

1. After the alarm has been set, you can review the alarm time by pressing and holding the AL1 or AL2 button for 2 seconds. The alarm time will be blinked on the display.
2. After 5 seconds, it will go back to normal time display.

### **TO STOP THE ALARM AND RESET THE ALARM READY FOR THE NEXT DAY**

1. When the alarm goes off, press the ON/OFF button to stop the alarm.
2. The alarm will be automatically reset and gets ready for the next day.

### **SNOOZE FUNCTION**

1. Press the SNOOZE button after an alarm goes off. The alarm will be silenced for 9 minutes and then sound again.
2. SNOOZE button can be pressed for 6 times. Then the alarm will be stopped automatically and gets ready for the next day.

### **LISTENING TO THE RADIO**

#### **TO TUNE THE RADIO TO DESIRED STATION MANUALLY**

1. Press the ON/OFF button to turn on the radio.
2. Press and hold the Tune/Volume button for approximate 2 seconds to select AM or FM band.
3. Press the Tune button to get into adjust the radio frequency.
4. Press and hold the + or – button for 2 seconds, the unit will scan upward or downward until a station with strong signal is searched and stops at this station.
5. You can adjust the frequency manually by pressing the + or – button when the radio frequency is still displayed.
6. Press the Volume button to get into the volume adjusting mode, then press the + or – button to adjust the volume to the desired level.

#### **PRESET RADIO STATION**

1. Press the ON/OFF button to turn on the radio.
2. Press and hold the TUNE/VOLUME button for approximate 2 seconds to select the band.

3. Press and hold the + or – button for 2 seconds to search for a desired radio station.
4. Press and hold the TIME/PRESET for approximate 2 seconds, then the preset station number “P01” will be displayed and flashes.
5. Press the + or – button to select a channel.
6. Press the TIME/PRESET button to save it.
7. Repeat step 4 to step 6 to save other stations. You can save up to 10 AM and 10 FM radio stations in the memory.

### **TO LISTEN TO A PRESET RADIO STATION**

1. Press the ON/OFF button to turn on the radio.
2. Press TIME/PRESET button to skip to the radio station you stored last time.
3. You can also press the + or – button to select a stored radio station.

### **USING SLEEP TIMER**

#### **TO SET SLEEP TIMER**

1. No matter the radio is off or on, press the SLEEP button once to activate the sleep timer to 90 minutes with “90” in the LED display and the radio is turned on.
2. Press the SLEEP button repeatedly to adjust the sleep timer to 80, 70, 60, 50, 40, 30, 20, 10 minutes and then OFF. “OFF” means to cancel the sleep timer and turn the radio off.
3. When the sleep timer is counting down, press the SLEEP button to display the remaining time.
4. If you want to change the sleep timer, press the SLEEP button repeatedly to the new sleep time.

#### **TO CANCEL SLEEP TIMER**

1. When the sleep timer is counting down, press the SLEEP button repeatedly until “OFF” is displayed.
2. Alternatively, press the ON/OFF button once to turn off the radio.

### **SPECIFICATIONS**

Frequency Range:	AM 520 – 1710 kHz FM 87.5 – 108 MHz
Power Supply:	AC 120V~ 60Hz
Backup Battery:	3V(2 pcs Size AAA battery not included)

**IMPORTANT:** Due to the continued functioning of revisions and improvements in the design of our products, specifications are subject to change without notice.